

Tripod stand

When using as a tripod, select the diameter according to the wheel axis, (if the wheel axis is narrower, unscrew the adjusting roller) then insert it into the rear wheel axis and support it, beware of tipping over.

When used as a block in transit, it is inserted between the front fender and the wheel.

See attached picture.

Use the product only for the purpose for which it is intended. Do not use for any other purpose.

Dispose of the product environmentally at the end of its useful life.

Country of origin: made in the EU .

MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice 38601, www.mefo.cz